



Box R Water Analysis Laboratory LLC

567 NW Second Street
Prineville, Oregon 97754
Phone: 541-447-4911
Fax : 541-447-4917

City of Antelope

October 16, 2014

C/O Mr. Don Fisher

P O Box 105

Antelope OR 97001


Dear Mr. Fisher,

Attached is a copy of your Lead and Copper, and Disinfection By-products, test results, sampled on September 2014. Please do not hesitate to call Box R Water Analysis Laboratory with any questions that you have in regards to your test results.

Thank-you for using Box R Water Analysis Laboratory, we appreciate your business.

Sincerely,

SK Miyazaki-Box R water Analysis Laboratory Director



NEILSON RESEARCH CORPORATION

Environmental Testing Laboratory

10/07/14

Sherri Miyazaki
Box R Waterlab
567 NW Second Street
Prineville, OR 97754

TEL: 541-447-4911
FAX (541) 447-4917

RE: BRW X016473-City of Antelope

Order No.: 1409B17

Dear Sherri Miyazaki:

Neilson Research Corporation received 5 sample(s) on 09/30/14 for the analyses presented in the following report.

The results relate only to the parameters tested or to the sample as received by the laboratory. This report shall not be reproduced except in full, without the written approval of Neilson Research Corporation. If you have any questions regarding these test results, please feel free to call.

Sincerely,
Neilson Research Corporation

Alec C Smith
Project Manager

Bacteria Nitrate Arsenic
 Reg SOC IOC Reg VOC
 DBP's TOC/Alk Lead & Copper
 Gross Alpha Rad 226/228 Uranium
 Other
Will be sent to State via Pdf On 10/7/14

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

CLIENT: Box R Waterlab
Project: BRW X016473-City of Antelope
Lab Order: 1409B17

Date: 07-Oct-14

CASE NARRATIVE

The analyses were performed according to the guidelines in the Neilson Research Corporation Quality Assurance Program. This report contains analytical results for the sample(s) as received by the laboratory.

Neilson Research Corporation certifies that this report is in compliance with the requirements of NELAP. No unusual difficulties were experienced during analysis of this batch except as noted below or qualified with data flags on the reports.

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

Box R Waterlab
567 NW Second Street
Prineville, OR 97754

Lab Order: 1409B17
NRC Sample ID: 1409B17-01A
Collection Date: 09/29/14 6:00:00 AM
Received Date: 09/30/14 9:30:00 AM
Reported Date: 10/07/14 12:14:49 PM

BRW X016473-City of Antelope

PWS ID#: 41-00042
Source ID: DIST-A
Sample Comp:

Client Sample ID: Bottle #2173
Sample Location: 45548 Collage, Outside Bib
Collectors Name: Don Fischer

ANALYTICAL RESULTS

Analyses	Code	Method	NELAC Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.00524		0.000515	mg/L	1.3 AL	10/05/14	BAR
Lead	1030	EPA 200.8	A	0.00124		0.000103	mg/L	0.015 A	10/05/14	BAR

Notes: ND - Not Detected at the MRL
MDL = Method Detection Limit

N.L. = No Limit

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

Box R Waterlab
567 NW Second Street
Prineville, OR 97754

Lab Order: 1409B17
NRC Sample ID: 1409B17-02A
Collection Date: 09/29/14 6:00:00 AM
Received Date: 09/30/14 9:30:00 AM
Reported Date: 10/07/14 12:19:31 PM

BRW X016473-City of Antelope

PWS ID#: 41-00042
Source ID: DIST-A
Sample Comp:

Client Sample ID: Bottle #2168
Sample Location: 45487 Collage, Outside Bib
Collectors Name: Don Fischer

ANALYTICAL RESULTS

Analyses	Code	Method	NELAC Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0278		0.000515	mg/L	1.3 AL	10/05/14	BAR
Lead	1030	EPA 200.8	A	0.000794		0.000103	mg/L	0.015 A	10/05/14	BAR

Notes: ND - Not Detected at the MRL
MDL = Method Detection Limit

N.L. = No Limit

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

Box R Waterlab
567 NW Second Street
Prineville, OR 97754

Lab Order: **1409B17**
NRC Sample ID: **1409B17-03A**
Collection Date: **09/29/14 6:00:00 AM**
Received Date: **09/30/14 9:30:00 AM**
Reported Date: **10/07/14 12:14:49 PM**

BRW X016473-City of Antelope

PWS ID#: 41-00042
Source ID: DIST-A
Sample Comp:

Client Sample ID: Bottle #2170
Sample Location: 45410 East St, Outside Bib
Collectors Name: Don Fischer

ANALYTICAL RESULTS

Analyses	Code	Method	NELAC Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.00268		0.000515	mg/L	1.3 AL	10/05/14	BAR
Lead	1030	EPA 200.8	A	0.000119		0.000103	mg/L	0.015 A	10/05/14	BAR

Notes: ND - Not Detected at the MRL
MDL = Method Detection Limit

N.L. = No Limit

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

Box R Waterlab
567 NW Second Street
Prineville, OR 97754

Lab Order: 1409B17
NRC Sample ID: 1409B17-04A
Collection Date: 09/29/14 6:00:00 AM
Received Date: 09/30/14 9:30:00 AM
Reported Date: 10/07/14 12:14:49 PM

BRW X016473-City of Antelope

PWS ID#: 41-00042
Source ID: DIST-A
Sample Comp:

Client Sample ID: Bottle #2172
Sample Location: 92259 Baird, Hose Bib
Collectors Name: Don Fischer

ANALYTICAL RESULTS

Analyses	Code	Method	NELAC Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0820		0.000515	mg/L	1.3 AL	10/05/14	BAR
Lead	1030	EPA 200.8	A	0.000379		0.000103	mg/L	0.015 A	10/05/14	BAR

Notes: ND - Not Detected at the MRL
MDL = Method Detection Limit

N.L. = No Limit

Neilson Research Corporation

245 South Grape Street, Medford, Oregon 97501 541-770-5678 Fax 541-770-2901

Analysis Report

ORELAP 100016
EPA OR00028

Box R Waterlab
567 NW Second Street
Prineville, OR 97754

Lab Order: 1409B17
NRC Sample ID: 1409B17-05A
Collection Date: 09/29/14 5:30:00 AM
Received Date: 09/30/14 9:30:00 AM
Reported Date: 10/07/14 12:14:49 PM

BRW X016473-City of Antelope

PWS ID#: 41-00042
Source ID: DIST-A
Sample Comp:

Client Sample ID: Bottle #2171
Sample Location: County Shop
Collectors Name: Don Fischer

ANALYTICAL RESULTS

Analyses	Code	Method	NELAC Accredited	Result	Qual	MRL	Units	EPA Limit	Date Analyzed	Analyst
Copper	1022	EPA 200.8	A	0.0621		0.0005	mg/L	1.3 AL	10/05/14	BAR
Lead	1030	EPA 200.8	A	0.00369		0.0001	mg/L	0.015 A	10/05/14	BAR

Notes: ND - Not Detected at the MRL
MDL = Method Detection Limit

N.L. = No Limit

CLIENT: Box R Waterlab
 Work Order: 1409B17
 Project: BRW X016473-City of Antelope

ANALYTICAL QC SUMMARY REPORT

TestCode: ICPMS_200.8_DW

Sample ID	MB-30992	SampType:	MBLK	TestCode:	ICPMS_200.8	Units:	mg/L	Prep Date:	10/03/14	RunNo:	76135			
Client ID:	ZZZZZ	Batch ID:	30992	TestNo:	EPA 200.8	(EPA 200.8)		Analysis Date:	10/05/14	SeqNo:	1132186			
Analyte		Result		MRL	SPK value	SPK Ref Val		%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper ND 0.000500
 Lead ND 0.000100

Sample ID	MB-30983	SampType:	MBLK	TestCode:	ICPMS_200.8	Units:	mg/L	Prep Date:	10/02/14	RunNo:	76135			
Client ID:	ZZZZZ	Batch ID:	30983	TestNo:	EPA 200.8	(EPA 200.8)		Analysis Date:	10/05/14	SeqNo:	1132218			
Analyte		Result		MRL	SPK value	SPK Ref Val		%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper ND 0.000500
 Lead ND 0.000100

Sample ID	LCS-30992	SampType:	LCS	TestCode:	ICPMS_200.8	Units:	mg/L	Prep Date:	10/03/14	RunNo:	76135			
Client ID:	ZZZZZ	Batch ID:	30992	TestNo:	EPA 200.8	(EPA 200.8)		Analysis Date:	10/05/14	SeqNo:	1132187			
Analyte		Result		MRL	SPK value	SPK Ref Val		%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper 0.1055 0.000500 0.1 0 106 85 115
 Lead 0.09825 0.000100 0.1 0 98.2 85 115

Sample ID	LCS-30983	SampType:	LCS	TestCode:	ICPMS_200.8	Units:	mg/L	Prep Date:	10/02/14	RunNo:	76135			
Client ID:	ZZZZZ	Batch ID:	30983	TestNo:	EPA 200.8	(EPA 200.8)		Analysis Date:	10/05/14	SeqNo:	1132219			
Analyte		Result		MRL	SPK value	SPK Ref Val		%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper 0.1008 0.000500 0.1 0 101 85 115
 Lead 0.09669 0.000100 0.1 0.000005155 96.7 85 115

Sample ID	1409B49-01AMS	SampType:	MS	TestCode:	ICPMS_200.8	Units:	mg/L	Prep Date:	10/03/14	RunNo:	76135			
Client ID:	ZZZZZ	Batch ID:	30992	TestNo:	EPA 200.8	(EPA 200.8)		Analysis Date:	10/05/14	SeqNo:	1132198			
Analyte		Result		MRL	SPK value	SPK Ref Val		%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Qualifiers: E Value above quantitation range H Holding times for preparation or analysis exceeded J Analyte detected below quantitation limits
 ND Not Detected at the Minimum Reporting Limit R RPD outside accepted recovery limits S Spike Recovery outside accepted recovery limits

NRC - Page 8 of 14

CLIENT: Box R Waterlab
 Work Order: 1409B17
 Project: BRW X016473-City of Antelope

ANALYTICAL QC SUMMARY REPORT

TestCode: ICPMS_200.8_DW

Sample ID	1409B49-01AMS	SampType: MS	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 10/03/14	RunNo: 76135					
Client ID:	ZZZZZ	Batch ID: 30992	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 10/05/14	SeqNo: 1132198					
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper	0.1041	0.000500	0.1	0.002158	102	70	130				
Lead	0.09790	0.000100	0.1	0.00137	96.5	70	130				

Sample ID	1409B16-01AMS	SampType: MS	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 10/02/14	RunNo: 76135					
Client ID:	ZZZZZ	Batch ID: 30983	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 10/05/14	SeqNo: 1132230					
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper	0.1001	0.000520	0.1	0.002548	97.5	70	130				
Lead	0.09761	0.000104	0.1	0.000594	97.0	70	130				

Sample ID	1409B49-01AMSD	SampType: MSD	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 10/03/14	RunNo: 76135					
Client ID:	ZZZZZ	Batch ID: 30992	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 10/05/14	SeqNo: 1132199					
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper	0.1033	0.000500	0.1	0.002158	101	70	130	0.1041	0.771	20	
Lead	0.09938	0.000100	0.1	0.00137	98.0	70	130	0.0979	1.50	20	

Sample ID	1409B16-01AMSD	SampType: MSD	TestCode: ICPMS_200.8	Units: mg/L	Prep Date: 10/02/14	RunNo: 76135					
Client ID:	ZZZZZ	Batch ID: 30983	TestNo: EPA 200.8	(EPA 200.8)	Analysis Date: 10/05/14	SeqNo: 1132231					
Analyte	Result	MRL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual

Copper	0.1011	0.000520	0.1	0.002548	98.6	70	130	0.1001	1.03	20	
Lead	0.09926	0.000104	0.1	0.000594	98.7	70	130	0.09761	1.67	20	

NRC - Page 9 of 14

Qualifiers: E Value above quantitation range H Holding times for preparation or analysis exceeded J Analyte detected below quantitation limits
 ND Not Detected at the Minimum Reporting Limit R RPD outside accepted recovery limits S Spike Recovery outside accepted recovery limits

X0164730

Lab Sample ID 1409B17-01A
Date Received 9/30/14
Time Received 9:30
Received By [Signature]

Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided.

If you have any questions please call: _____
Boswell Water Analytical Laboratory
567 NW Second Street
Prineville, Oregon 97754
541-447-4911

TO BE COMPLETED BY RESIDENT

Water was last used: Time 12pm (am/pm) Date 9-28-14

Sample was collected: Time 6am (am/pm) Date 9-29-14

Name of Water System City of Astoria PWS ID 41- 00042

Sample Collected by Don Fisher Bottle # 2173

Address 45548 Collage Space # _____

Faucet Location OUTSIDE BIB

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 9-29-14

X116473 (2)

Lab Sample ID 1409817-02A
Date Received 9/30/14
Time Received 9:30
Received By [Signature]

Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days, to the Laboratory.

Box R Water Analysis Laboratory
567 NW Second Street
Prineville, Oregon 97754
541-447-4911

If you have any questions please call: _____

TO BE COMPLETED BY RESIDENT

Water was last used: Time 10 pm (am/pm) Date 9-28-14

Sample was collected: Time 6 am (am/pm) Date 9-29-14

Name of Water System City of Antelope PWS ID 41- 00014

Sample Collected by Don Fischer Bottle # 2168

Address 45487 Collage Space # _____

Faucet Location outside b7b

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 9-29-14

X016474 (3)

Lab Sample ID 1400817-03A
Date Received 9/30/14
Time Received 9:30
Received By B

Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

Box R Water Analysis Laboratory
567 NW Second Street
Prineville, Oregon 97754
541-447-4911

If you have any questions please call: _____

TO BE COMPLETED BY RESIDENT

Water was last used: Time 10 pm (am/pm) Date 9-28-14

Sample was collected: Time 6 am (am/pm) Date 9-29-14

Name of Water System City of Antelope PWS ID 41- _____

Sample Collected by Don Fischer Bottle # 2170

Address 45410 East St Space # _____

Faucet Location Outside bib

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature Don Fischer Date 9-29-14

XD16474 (4)

Lab Sample ID 1409817-04A
Date Received 9/30/14
Time Received 9:30
Received By [Signature]

Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated by the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided usually 10 working days from the time of sample collection.

Don R. Water Analysis Laboratory
507 NW Second Street
Prineville, Oregon 97754
541-447-4911

If you have any questions please call: _____

TO BE COMPLETED BY RESIDENT

Water was last used: Time 12pm (am/pm) Date 9-28-14

Sample was collected: Time 6am (am/pm) Date 9-29-14

Name of Water System City of Antelope PWS ID 41-00012

Sample Collected by Don Fischer Bottle # 2172

Address 92259 Baird Space # _____

Faucet Location hose bib

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 9-29-14

X016474 (5)

Lab Sample ID 14098105A
Date Received 9/30/14
Time Received 9:30
Received By [Signature]

Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
3. Tightly cap the sample bottle. Please carefully complete this form.
4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 48 working days from the time of sample collection.

If you have any questions please call: _____

TO BE COMPLETED BY RESIDENT

Water was last used: Time 5:30 pm (am/pm) Date 9-28-14

Sample was collected: Time 5:30 am (am/pm) Date 9-29-14

Name of Water System City of Antelope PWS ID 41- 00042

Sample Collected by Don Fischer Bottle # 2171

Address County Shop Space # _____

Faucet Location Outside bib

Note any plumbing repairs or replacements made since last sampling event:

I have read the above directions and have taken a tap sample in accordance with these directions.

Signature [Signature] Date 9-29-14